






LIGHT SOURCE REMOVING INSTRUCTION		Creation date (dd/mm/yyyy) :	10/10/2022
		Last update date (dd/mm/yyyy) :	10/10/2022
1	Supplier's name or trade mark	ADEO Services,	
2	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN	
3	Model Identifier - Luminaire Supplier reference	OS2105-RB/OS2105-RW/OS2105-SB/OS2105-SW/OS2105-SZ	
4	Light sources maker model	S220-9400GB	

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	Open the base		by hand
Step 2	Pull out the wire		by hand
Step 3	Unscrew the fixing screws on the drive and terminal		screwdriver
Step 4	Unscrew the lamp holder fixing screw (the one with round gasket)		screwdriver
Step 5	Take out the LED board , the removal procedure is complete		by hand
Step 6			
Step 7			
Step 8			