

LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :










01/11/2022

Last update date (dd/mm/yyyy) :

01/11/2022

1	General information	Supplier's name or trade mark	INSPIRE
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	2103-S-BK; 2103-S-WH
4		Light sources maker model	2103

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	The whole product		
Step 2	Open the reflector cup with a screwdriver		Slotted screwdriver
Step 3	Take out the reflector cup		
Step 4	Unscrew the screws with a screwdriver		Cross screwdriver
Step 5	Take out the plastic cover		
Step 6	Loosen the plastic screw fixing the wire with a screwdriver		Slotted screwdriver
Step 7	Pull out the fiberglass tube		
Step 8	Pull out the PCB, and weld it down with a soldering iron		Soldering iron
Step 9	The light source		
Step 10			