

Instrukcja obsługi

Rekuperator HC4, HC6

Basic, Comfort, Comfort Plus



Model: SX-RHC4HEB – HC4 HE Basic
SX-RHC4HEC – HC4 HE Comfort
SX-RHC4HRC – HC4 HR Comfort
SX-RHC4HECP – HC4 HE Comfort Plus
SX-RHC4HRCP – HC4 HR Comfort Plus

SX-RHC6HEB – HC6 HE Basic
SX-RHC6HEC – HC6 HE Comfort
SX-RHC6HRC – HC6 HR Comfort
SX-RHC6HECP – HC6 HE Comfort Plus
SX-RHC6HRCP – HC6 HR Comfort Plus