^) a	LIGHT SOURCE REMOVING INSTRUCTION	Creation date (dd/mm/yyyy) : 29/04/2021	l l
	12100	ALITY	Last update date (dd/mm/yyyy) : 22/06/2022	2
1	neral informati	Supplier's name or trade mark	INSPIRE	
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN	
3		Model Identifier - Luminaire Supplier reference	G17799	
4		Light sources maker model	G17729-XXDB	

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	unscrew	[01]	by hand
Step 2	Take off the metal ring	officer (1)	by hand
Step 3	Take off the diffuser	700 20 To 8704 700	by hand
Step 4	Loosen the screws on the wire plate and lamp board	02	by hand
Step 5	take off the wire plate		by hand
Step 6	press the terminal block		by hand
Step 7	pull out the red&black wires		by hand
Step 8	take out the lamp board	jo3	by hand
Step 9	press the terminal block		by hand
Step 10	pull out the brown&blue wires		by hand
Step 11	pull out the brown&blue wires	Sacration of the sacrat	by hand
Step 12	let go		by hand
Step 13	take out the driver		by hand
Step 14	unscrew the driver screws		by hand