



## LIGHT SOURCE REMOVING INSTRUCTION

Creation date (dd/mm/yyyy) :






15/09/2022

Last update date (dd/mm/yyyy) :

15/09/2022

1	General information	Supplier's name or trade mark	NO NAME
2		Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN
3		Model Identifier - Luminaire Supplier reference	DL-GP3AC03BR-2
4		Light sources maker model	DL-GP3AC03BR-2

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explanation of the step	Pictures	Tools
Step 1	Remove the light through plate and draw out the light through plate with a suction cup		sucking disc
Step 2	Turn the screw counterclockwise with a Phillips screwdriver		screwdriver
Step 3	Solder the lower connection wire with an electric iron.		electric soldering iron
Step 4	pry out the optical PCB with a flat-head screwdriver		screwdriver
Step 5	Turn the screw (loose) counterclockwise with a Phillips screwdriver and remove.		screwdriver